

Fonte Bath Shower Mixer

FLOOR-STANDING • BATH SHOWER MIXER • SOLID BRASS

CL – BF – 002 – ALL FINISHES

FIXING Solid Floor	SUPPLIES Hot & Cold • Flexi Tails	MIN. PRESSURE 0.5 bar	FITTER Competent Person
-----------------------	--------------------------------------	--------------------------	----------------------------

BEFORE FITTING

- Isolate both hot and cold supplies before any work begins.
- The column fixes to a solid floor. Confirm pipe positions at the fixing point before drilling.
- Check the spout serves the bath: exit height 1011 mm above finished floor, projection 174.4 mm over the rim.
- Flush both supply lines through before connection.

IN THE BOX

Column and spout assembly • shower handset, bracket and 1.5 m hose • two handles — knurled and smooth • flexi tails • floor fixing kit and base cover

FITTING SEQUENCE

- Set out**
Position the base against the bath. Check spout reach over the rim and handset clearance before marking.
- First fix**
Mark the floor fixings through the base plate. Drill and plug; route hot and cold to the fixing point.
- Fix the base**
Bolt the base plate down, checking level in both directions before the final tighten. Base stands 45 mm.
- Connect**
Connect the flexi tails to the isolated supplies — hot to the left, cold to the right.
- Dress the column**
Seat the column on the base, secure, and slide the base cover down to the floor.
- Fit the handle**
Fit the knurled or the smooth handle — both are supplied — and secure. The other stores for a later change of mind.
- Handset**
Connect the 1.5 m hose between outlet and handset; seat the handset in its bracket.
- Test**
Restore supplies slowly. Run hot and cold to full, operate the diverter, and check every joint under pressure.

NOTE

Where the instruction supplied in the box differs from this sheet, follow the supplied instruction. Minimum operating pressure 0.5 bar.