

Cast Bathroom Lock

MORTICE BATHROOM LOCK • 76MM CASE • 57MM BACKSET

CL – BL – 001 – [ALL FINISHES]

MARKING Square & marking knife	MORTISE Chisel & mallet	PILOT Ø 16 mm auger + Ø 2 mm	FIXING PZ2 screwdriver
-----------------------------------	----------------------------	---------------------------------	---------------------------

FITTING SEQUENCE • LOCK AND STRIKE PLATE

- 1

MARK
Hold the lock against the door face at handle height and mark the case depth and the two follower centres. Square the lines across the door edge.
- 3

BORE
Drill the follower holes through both faces at **57 mm** backset and **57 mm** centres — the upper for the lever spindle, the lower for the turn.
- 5

STRIKE
Close the door and mark the bolt positions on the frame. Mortise for both bolts, recess the strike plate flush, and screw it home.

- 2

MORTISE
Bore the edge to a depth of **78 mm** with a **Ø 16 mm** auger, then pare the mortise square. The case should slide in without forcing.
- 4

RECESS
Seat the lock, scribe the faceplate, and chisel a shallow recess so it sits flush with the door edge. Fix with the supplied screws.
- 6

CHECK
The latch should close cleanly and the deadbolt throw fully with a quarter turn. To reverse the latch for the opposite hand, follow the maker's instructions — do not open the case.

FIRE DOOR INSTALLATIONS

Intumescent protection must be fitted around the lock case and forend to achieve the fire rating. Follow the door leaf certificate at all times and do not modify the leaf beyond its certified allowances.

CARE

Wipe with a soft, dry cloth. No abrasives, no solvents, no polish. Living finishes will deepen in tone with use — this is intended.

SUPPORT

Certification documents are available on request. Write to studio@castlondon.co.uk quoting the serial on this sheet.

CAST STANDARD MORTICE LOCK SERIES 02 / HARDWARE FD30 / FD60 QC PASSED • CL-QC-001