Asta Cabinet Pull

KNURLED BAR CABINET PULL · ALUMINIUM · 128 / 192 / 320 CENTRES

CL — CP — 001 — [ALL FINISHES]

MARKING	DRILLING	FIXING	DRIVER
Pencil, square & template	5 mm bit	2 × M4 screws, supplied	Pozi / Phillips

FITTING SEQUENCE · ONE PULL PER DOOR OR DRAWER

1 MARK

Mark the two hole centres on the face of the door or drawer, level and square: 128, 192 or 320 mm apart to suit the pull.

2 DRILL

Drill straight through with a 5 mm bit. Back the face with scrap timber so the exit hole does not split.

3 SCREWS

Use the two M4 screws supplied. On an unusually thick or thin door, swap for M4 screws that engage 8–10 mm into each post — each post is tapped 10 mm deep.

4 FIX

Hold the pull to the face and drive both screws from the inside. Tighten evenly by hand until the posts sit flat — do not overtighten into aluminium.

BEFORE YOU START

Sold singly — order one per door or drawer. Two M4 fixing screws are supplied with each pull. Keep the knurl the same way up on every pull in a run.

CARE

Wipe with a soft, dry cloth. No abrasives, no solvents, no polish. Living finishes will deepen in tone with use — this is intended.

SUPPORT

Technical documents are available on request. Write to studio@castlondon.co.uk quoting the serial on this sheet.

ASTA CABINET PULL SERIES 01 / HARDWARE ALUMINIUM QC PASSED · CL-QC-001