Asta Cabinet Pull Short

KNURLED T-BAR CABINET PULL · SINGLE FIXING · ALUMINIUM · 95 MM

CL — CP — 002 — [ALL FINISHES]

MARKING	DRILLING	FIXING	DRIVER
Pencil & square	5 mm bit	1 × M4 screw, supplied	Pozi / Phillips

FITTING SEQUENCE · ONE PULL PER DOOR OR DRAWER

1 MARK

Mark a single hole centre on the face of the door or drawer — centred on a drawer, or in line with the hinge-side pulls on a door.

2 DRILL

Drill straight through with a **5 mm** bit. Back the face with scrap timber so the exit hole does not split.

3 SCREW

Use the **M4** screw supplied. On an unusually thick or thin door, swap for an M4 screw that engages **8–10 mm** into the foot — it is tapped **10 mm** deep.

4 FIX

Hold the pull level, bar horizontal, and drive the screw from the inside. Tighten by hand until the foot sits flat — do not overtighten into aluminium.

BEFORE YOU START

Sold singly with one M4 fixing screw. A single fixing lets the bar turn under load — set it level and tighten firmly so every pull in a run sits square.

CARE

Wipe with a soft, dry cloth. No abrasives, no solvents, no polish. Living finishes will deepen in tone with use — this is intended.

SUPPORT

Technical documents are available on request. Write to studio@castlondon.co.uk quoting the serial on this sheet.

ASTA · CABINET PULL SHORT · SERIES 01 / HARDWARE · ALUMINIUM · QC PASSED · CL-QC-001