Cast Edge Pull

ROUND EDGE PULL · POCKET DOOR · SOLID BRASS · Ø 30

CL — EP — 001 — [ALL FINISHES]

MARKING	BORE	DEPTH	FIXING
Pencil & square	Ø 25 mm Forstner bit	19 mm stop	Clear adhesive

FITTING SEQUENCE · LEADING EDGE OF THE DOOR

1 **MARK**
With the door off the pocket frame, mark the centre of the leading edge at hand height, halfway across the door's thickness.

2 **BORE**
Bore a **Ø 25 mm** hole **19 mm** deep, square to the edge, with a depth stop. Keep the drill level so the flange seats evenly.

3 **TEST**
Push the pull in dry. The body should enter firmly and the flange sit down on the edge all round, with the crescent ledge at the bottom.

4 **FIX**
Apply a thin bead of adhesive to the body, push the pull home with the ledge at the bottom, and wipe away any squeeze-out before it sets.

BEFORE YOU START
The edge pull lets you draw a door back out of the pocket when it has run fully in. Check the door is thick enough for a 30 mm flange. On a privacy door, the Cast Pocket Door Lock already includes its own edge pull — order this one for passage doors or as a spare.

CARE

Wipe with a soft, dry cloth. No abrasives, no solvents, no polish. Living finishes will deepen in tone with use — this is intended.

SUPPORT

Technical documents are available on request. Write to studio@castlondon.co.uk quoting the serial on this sheet.

CAST · EDGE PULL · SERIES 02 / HARDWARE · SOLID BRASS · QC PASSED · CL-QC-001