

Filo Lever Square

TAPERED BLADE • SQUARE ROSE • SOLID BRASS

CL – FL – 002

SUPPLIED

Levers on square roses • 1 pair

Concealed base plates • 1 pair

Spindle and fixing screws

REQUIRED, NOT SUPPLIED

Latch or lock • to suit supplied spindle

Screwdriver • pozi

Bradawl and pencil

INSTALLATION

- 01** Check the door is between 35 and 55 mm thick. Outside this range the concealed fixing will not draw up correctly.

02 Fit the latch or lock first, to the backset specified for the door.

03 Mark and drill the spindle hole through the door, centred on the follower and square to both faces.

04 Offer a concealed base plate to each face, centred on the hole. Mark the three fixing positions and start them with a bradawl.
- 05** Screw both base plates down. Tighten the three screws evenly in rotation so each plate pulls up square.

06 Pass the spindle through the follower so an equal length projects from each face.

07 Engage each lever on the spindle, then seat the square cover rose over its base plate. Align the rose edges with the door edges before securing.

08 Test before finishing: the blade must sit level, return cleanly, and the latch must withdraw fully and re-latch.

FIRE DOORS

Fire rated FD30 and FD60. Fit only with the supplied fixings and with intumescent protection to the latch or lock as specified for the doorset. Do not modify the lever, rose, base plate or spindle. Any alteration voids the fire assessment.

CARE

Clean with warm soapy water and a soft cloth. Dry immediately. No harsh chemicals are needed and none should be used — never abrasives, scouring pads, bleach, solvents or proprietary metal polish, all of which will cut through the finish. Living finishes will shift in tone with handling and time; this is intended, not a defect, and is covered by the guarantee.