Incasso Flush Pull Reeded Long

REEDED RECTANGULAR FLUSH PULL · POCKET DOOR · SOLID BRASS · 105 / 175

CL — FP — 004 — [ALL FINISHES]

MARKING	RECESS	DEPTH	FIXING
Pencil, square & knife	Router & chisel	10 mm stop	Adhesive & pin hammer

FITTING SEQUENCE · ONE PULL ON EACH FACE

1 **MARK**

With the door off the pocket frame, mark the pull centre on each face at hand height, long side vertical, clear of the leading edge and any lock.

2 **RECESS**

Rout the recess **10 mm** deep: **85 × 43.6 mm** for the 105, **155 × 43.6 mm** for the 175. Square the corners with a chisel.

3 **TEST**

Offer the pull to the recess dry. The body should drop in cleanly and the face plate should lie flat on the door with no rock.

4 **FIX**

Bed the body on a thin line of adhesive, seat the plate square to the door edge and secure with the pins supplied. Wipe away any squeeze-out.

BEFORE YOU START

Sold singly — order two for a door that slides from both faces. Fit before the door goes into the pocket frame. Use the 175 on a full-height door and the 105 on cupboards in the same finish.

CARE

Wipe with a soft, dry cloth. No abrasives, no solvents, no polish. Living finishes will deepen in tone with use — this is intended.

SUPPORT

Technical documents are available on request. Write to studio@castlondon.co.uk quoting the serial on this sheet.

INCASSO FLUSH PULL REEDED LONG SERIES 02 / HARDWARE SOLID BRASS QC PASSED · CL-QC-001