Asta Cabinet Knob

KNURLED ROUND CABINET KNOB · SINGLE FIXING · ALUMINIUM · Ø42.5

CL — KC — 001 — [ALL FINISHES]

MARKING	DRILLING	FIXING	DRIVER
Pencil & square	5 mm bit	1 × M4 screw, supplied	Pozi / Phillips

FITTING SEQUENCE · ONE KNOB PER DOOR OR DRAWER

1 MARK

Mark a single hole centre on the face — centred on a drawer, or on the closing stile of a door, in line with any pulls in the run.

2 DRILL

Drill straight through with a 5 mm bit. Back the face with scrap timber so the exit hole does not split.

3 SCREW

Use the M4 screw supplied. On an unusually thick or thin door, swap for an M4 screw that engages 8–10 mm into the stem — it is tapped 10 mm deep.

4 FIX

Hold the knob square to the face and drive the screw from the inside. Tighten by hand until the stem sits flat — do not overtighten into aluminium.

BEFORE YOU START

Sold singly with one M4 fixing screw. Same knurl as the Asta Cabinet Pull, so knobs and pulls can be mixed across one run of joinery in a single finish.

CARE

Wipe with a soft, dry cloth. No abrasives, no solvents, no polish. Living finishes will deepen in tone with use — this is intended.

SUPPORT

Technical documents are available on request. Write to studio@castlondon.co.uk quoting the serial on this sheet.

ASTA · CABINET KNOB · SERIES 01 / HARDWARE · ALUMINIUM · QC PASSED · CL-QC-001