

Asta Lever

KNURLED BAR • ROUND ROSE • SPRUNG • 8 MM SPINDLE

CL – LV – 001

SUPPLIED

Levers on roses • 1 pair

Spindle • 8 mm

Fixing screws • set

REQUIRED, NOT SUPPLIED

Latch or lock • 8 mm follower

Screwdriver • pozi

Bradawl and pencil

INSTALLATION

- 01** Fit the latch or lock first, to the backset specified for the door. Check the follower is 8 mm.

02 Mark and drill the spindle hole through the door, centred on the latch follower and square to both faces.

03 Offer a rose to each face, centred on the spindle hole. Mark the fixing positions and start them with a bradawl.

04 Fix the roses to the door using the supplied screws. Tighten evenly and do not overtighten.
- 05** Pass the spindle through the latch follower so an equal length projects from each face.

06 Engage the first lever on the spindle and seat it against the rose. Fit the second lever to the opposite face.

07 Secure both levers. Check each sits level and square to the door.

08 Test before finishing: the lever must return to horizontal under its own spring, and the latch must withdraw fully and re-latch cleanly.

FIRE DOORS

On FD30 and FD60 timber fire doors, fit only with the supplied fixings and with intumescent protection to the latch or lock as specified for the doorset. Do not modify the lever, rose or spindle. Any alteration voids the fire assessment.

CARE

Wipe with a soft, dry cloth. For marks, use a barely damp cloth and dry immediately. Never use abrasives, scouring pads, bleach, solvents or proprietary metal polish — all of these will cut through the finish. Living finishes will shift in tone with handling and time; this is intended, not a defect, and is covered by the guarantee.