

Velo Lever Round

SUPPLIED IN PAIRS · SPINDLE & FIXINGS INCLUDED

CL — LV — 003

YOU WILL NEED P22 screwdriver · pencil · bradawl	DOOR PREP Latch or lock to suit supplied spindle	TIME Approx. 15 minutes per door
---	---	-------------------------------------

PREPARATION

- 01 Check the set before starting. Two levers, spindle, fixing screws and grub screws should be present. Do not fit a damaged component — contact us first.
- 02 Fit the latch or lock case to the door edge in the usual way, with the follower at your handle height. The Velo suits a standard tubular latch.
- 03 Mark the fixing positions. Pass the spindle through the follower, offer up a rose to each face and check it sits square and level. Mark the fixing holes through the base plate with a bradawl.
- 04 Pilot-drill the marks. A small pilot hole for each fixing screw prevents the timber splitting and keeps the rose true.

ASSEMBLY

- 05 Fix the base plates. Screw each base plate to the door face. Do not overtighten — the plate must sit flat, not dish into the timber.
- 06 Insert the spindle through the follower, equal length showing to each face.
- 07 Slide each lever over the spindle and onto its base plate, cover barrel seating over the plate so the rose reads as one piece against the door.
- 08 Secure the grub screw on the underside of each barrel with the key supplied, and check the levers return level and the latch throws cleanly. Ease the fixings a quarter-turn if the action binds.

NOTE

These steps describe general practice for a sprung lever on a concealed mini rose. Where the instruction supplied in the box differs, follow the supplied instruction. Latch, lock and door preparation to suit the supplied spindle.

CARE

Wipe with a dry, soft cloth. No abrasives, no solvents, no polish — wear goes through the finish to the substrate and is not covered by the guarantee.