Cast Pocket Door Lock

POCKET DOOR PRIVACY LOCK · HOOK BOLT · 40MM BACKSET · FLUSH TURN

CL — PD — 001 — [ALL FINISHES]

MARKING	MORTISE	RECESS	FIXING
Square & marking knife	Chisel & mallet	Ø 48 mm Forstner bit	PZ2 screwdriver

FITTING SEQUENCE · LOCK, FLUSH FURNITURE AND KEEP

1 MARK

With the door off the pocket frame, mark the lock height on the leading edge and square it across both faces. Mark the turn centre at **40 mm** backset on each face.

2 MORTISE

Mortise the leading edge, centred on the door thickness, to take the **67 mm** case. The case should slide in without forcing.

3 RECESS

On each face, bore a **Ø 48 mm** recess **10.5 mm** deep on the backset mark. Drill the **8 mm** spindle hole through between the two recesses.

4 FIT THE LOCK

Seat the case, scribe the forend and chisel a shallow recess so it sits flush with the edge. Fix with the screws supplied.

5 FURNITURE

Fit the flush turn on the room side and the coin release on the outer face, both engaged on the spindle and sitting flush. Bore the leading edge to suit the edge pull and press it home flush.

6 KEEP

Hang the door, slide it closed and mark the hook bolt on the jamb. Mortise for the bolt, recess the keep flush and fix. The turn should throw the bolt cleanly into the keep.

BEFORE YOU START

Fit the lock, flush furniture and edge pull before the door goes into the pocket frame — access to the leading edge is limited once it is hung. Confirm the door is 35–52 mm thick. No fire certificate is supplied with this lock.

CARE

Wipe with a soft, dry cloth. No abrasives, no solvents, no polish. Living finishes will deepen in tone with use — this is intended.

SUPPORT

Technical documents are available on request. Write to studio@castlondon.co.uk quoting the serial on this sheet.

CAST STANDARD · POCKET DOOR LOCK · SERIES 02 / HARDWARE · HOOK BOLT · QC PASSED · CL-QC-001