

Cast Wall-Hung Toilet

WALL-HUNG PAN · RIMLESS · VITREOUS CHINA

CL – TL – 001

IN THE BOX Pan · soft-close seat · fixing kit	BEFORE YOU START Frame installed, wall finished	YOU WILL NEED Level · lubricant for seals · saw for connectors	CARE Never overtighten against china
---	---	--	--

SEQUENCE

- 01 Start at the frame.** The pan hangs from a concealed cistern frame — Cast Concealed Cistern CL-WC-001 or equivalent, with fixing studs at 178 mm centres and the outlet centre 320 mm above finished floor. Frame fixed, wall closed and finished first.
- 02 Offer up and mark.** Offer the pan to the studs and check the inlet (Ø 57) and outlet (Ø 100) alignment against the frame connectors.
- 03 Cut the connectors.** Trim the frame's inlet and outlet connectors to length so the pan sits flush to the wall face — measure twice, cut square, chamfer the cut edges.
- 04 Lubricate and hang.** Lubricate the seals, then slide the pan onto the studs, engaging both connectors, and push home evenly to the wall.
- 05 Fix.** Fit the supplied washers and caps and tighten each side a little at a time — firm and even, never forced against the china.
- 06 Fit the seat.** Top-fixing at 150 mm centres (Ø 15). The quick-release button lifts the whole seat off for cleaning; refit it by locating and clicking home.
- 07 Test.** Run both flushes, check the wall-face seal and the connector joints, and confirm the pan carries weight without movement.

NOTE

Where the instruction supplied in the box differs from this sheet, follow the supplied instruction. Vitreous china cracks under point load — tighten fixings evenly and by hand-feel; installation by a competent person.