

Asta Turn

KNURLED T-BAR • ROUND ROSE • TURN & RELEASE

CL – TT – 002

SUPPLIED

Turn on rose • inside face
Release on rose • outside face
Turn spindle
Fixing screws • set

REQUIRED, NOT SUPPLIED

Bathroom lock • 5 mm turn follower
Screwdriver • pozi
Bradawl and pencil

INSTALLATION

- 01 Fit the bathroom lock first, to the backset specified for the door. Check its turn follower is 5 mm.

02 Mark and drill the turn spindle hole through the door, centred on the lock's turn follower and square to both faces.

03 Offer a rose to each face, centred on the hole. Mark the fixing positions and start them with a bradawl.

04 Fix both roses to the door using the supplied screws. Tighten evenly and do not overtighten.
- 05 Pass the turn spindle through the lock's turn follower so it engages both roses.

06 Fit the knurled T-bar turn to the INSIDE face, engaged on the spindle and seated against its rose.

07 Fit the coin release to the OUTSIDE face. Set it so the slot reads vertical when the door is unlocked.

08 Test before finishing: the T-bar must throw and withdraw the deadbolt cleanly, and a coin in the outside slot must release it fully.

EMERGENCY RELEASE & FIRE DOORS

The outside face carries an emergency coin release. On installation, confirm a coin turns the slot and withdraws the bolt fully from outside, and show the occupant where it is. Never paint over the release or cover it with an escutcheon. This turn is NOT fire rated and must not be fitted to an FD30 or FD60 doorset.

CARE

Wipe with a soft, dry cloth. For marks, use a barely damp cloth and dry immediately. Never use abrasives, scouring pads, bleach, solvents or proprietary metal polish — all of these will cut through the finish. Living finishes will shift in tone with handling and time; this is intended, not a defect, and is covered by the guarantee.