

Filo Turn Square

TURN & RELEASE • SQUARE ROSE • SOLID BRASS

CL – TT – 003

SUPPLIED

Turn on square rose • inside face

Release on square rose • outside face

Turn spindle

Fixing screws • set

REQUIRED, NOT SUPPLIED

Bathroom lock • to suit supplied spindle

Screwdriver • pozi

Bradawl and pencil

INSTALLATION

- 01 Fit the bathroom lock first, to the backset specified for the door.

02 Mark and drill the turn spindle hole through the door, centred on the lock's turn follower and square to both faces.

03 Offer a base plate to each face, centred on the hole. Mark the three fixing positions and start them with a bradawl.

04 Screw both base plates down, tightening the three screws evenly in rotation so each plate pulls up square.
- 05 Pass the turn spindle through the lock's turn follower so it engages both faces.

06 Fit the oval turn to the INSIDE face, engaged on the spindle.

07 Fit the coin release to the OUTSIDE face. Set the slot vertical when the door is unlocked.

08 Seat both square cover roses and align their edges with the door edges before securing. Test that the turn throws and withdraws the bolt cleanly, and that a coin releases it from outside.

EMERGENCY RELEASE & FIRE DOORS

The outside face carries an emergency coin release. On installation, confirm a coin turns the slot and withdraws the bolt fully from outside, and show the occupant where it is. Never paint over the release or cover it with an escutcheon. No fire rating is claimed for this product — do not fit it to an FD30 or FD60 doorset.

CARE

Clean with warm soapy water and a soft cloth. Dry immediately. No harsh chemicals are needed and none should be used — never abrasives, scouring pads, bleach, solvents or proprietary metal polish, all of which will cut through the finish. Living finishes will shift in tone with handling and time; this is intended, not a defect, and is covered by the guarantee.