

Velo Turn

TURN & RELEASE · FIXINGS INCLUDED

CL — TT — 004

YOU WILL NEED P22 screwdriver · pencil · bradawl	DOOR PREP Bathroom mortice lock to suit supplied spindle	TIME Approx. 10 minutes per door
---	---	-------------------------------------

PREPARATION

- 01 Check the set before starting. Turn assembly, release assembly, spindle, fixing screws and grub screws should be present. Do not fit a damaged component — contact us first.
- 02 Fit the bathroom mortice lock to the door edge in the usual way, with the turn follower at your chosen height — conventionally just above or below the lever.
- 03 Mark the fixing positions. Pass the spindle through the follower, offer the turn to the inside face and the release to the outside, check both sit square, and mark the fixing holes with a bradawl.
- 04 Pilot-drill the marks. A small pilot hole for each fixing screw prevents the timber splitting and keeps the roses true.

ASSEMBLY

- 05 Fix the base plates to each door face. Do not overtighten — each plate must sit flat, not dish into the timber.
- 06 Insert the spindle through the follower with the correct length showing to each face.
- 07 Fit the turn to the inside and the release to the outside, each cover seating over its plate so the rose reads as one piece against the door.
- 08 Secure the grub screws with the key supplied, then test: the turn should throw the bolt with a light quarter-turn, and a coin in the outside slot should release it. Ease the fixings a quarter-turn if the action binds.

NOTE

These steps describe general practice for a turn and release on a concealed mini rose. Where the instruction supplied in the box differs, follow the supplied instruction. Lock and door preparation to suit the supplied spindle.

CARE

Wipe with a dry, soft cloth. No abrasives, no solvents, no polish — wear goes through the finish to the substrate and is not covered by the guarantee.