

# Fonte Wall-Mounted Basin Mixer

SINGLE LEVER · WALL MOUNTED · 240 / 140 SPOUT

CL – WB – 002 · INSTALLATION BY A COMPETENT PLUMBER

## BEFORE FITTING

Minimum operating pressure 0.5 bar. The valve body is concealed — it sets 85.5 mm behind the finished wall face, so confirm wall build-up before first fix. Spout and valve roses sit at 100 mm centres. Isolate hot and cold supplies before starting, and flush both lines before the valve is connected.

|                            |                          |                      |                      |                     |                             |
|----------------------------|--------------------------|----------------------|----------------------|---------------------|-----------------------------|
| 01<br>Concealed valve body | 02<br>Spout · 240 or 140 | 03<br>Wall roses × 2 | 04<br>Knurled handle | 05<br>Smooth handle | 06<br>Flexi tails · fixings |
|----------------------------|--------------------------|----------------------|----------------------|---------------------|-----------------------------|

## SEQUENCE

- 01 Isolate.** Shut off the hot and cold supplies and open a downstream tap to drain residual pressure.
- 02 First fix.** Set the concealed valve body into the wall with the face datum 85.5 mm forward of the body — check the finished wall line before it is built in. The spout outlet and the valve sit at 100 mm centres; check level across both.
- 03 Connect.** Hot and cold to the valve at G½ via the supplied flexi tails — hot to the left as viewed. Flush both lines through before final connection.
- 04 Close the wall.** Finish and seal the wall surface, then make good tight to both fixing points.
- 05 Roses.** Fit both wall roses flush to the finished face.
- 06 Spout.** Thread the spout home into its wall fitting and secure with the M5 grub screw on the underside, 5 mm from the face. Do not overtighten against the plated finish.
- 07 Handle.** Fit your chosen handle — the knurled and the smooth both travel in the box; either draws onto the spindle and secures with its grub screw. The other is yours to keep, or to change your mind with later.
- 08 Test.** Restore supplies slowly. Run the lever through its full travel, hot and cold, and check every joint for weeps before signing off.

This sheet is a general sequence. Where the instruction supplied in the box differs from this sheet, follow the supplied instruction. Aftercare: warm water and a soft cloth only – no abrasives, no solvents. Living finishes patinate with use.