

Fonte Basin Mixer

SINGLE LEVER · DECK MOUNTED · SHORT & TALL

CL – BB – 002 · APPLIES TO BOTH HEIGHTS · ALL FINISHES

FITTER Qualified installer	SUPPLIES Hot & cold · min 0.5 bar	DECK CUTOUT To suit tails · check on site	IN THE BOX Tap · 2 handles · tails · fixing kit
--	---	---	---

FITTING SEQUENCE

01 Isolate the supplies

Turn off hot and cold at the isolation valves and open the old tap to drain down before starting.

02 Check the parts

Tap body with the knurled handle fitted, the smooth handle boxed alongside, flexible tails, and the fixing kit — stud, rubber washer, retaining plate and nut. Report any shortage before fitting.

03 Fit the tails and stud

Wind the flexible tails into the seats in the tap base by hand — no sealant, no tools on the seats. Fit the fixing stud finger-tight beside them.

04 Seat the tap

Feed the tails and stud through the tap hole and seat the base gasket flat on the basin or deck. Face the spout over the bowl.

05 Secure from below

From underneath, pass the rubber washer and retaining plate over the tails onto the stud and tighten the nut until the tap sits firm. Do not overtighten against stone or ceramic.

06 Connect the supplies

Connect the tails to the isolation valves — hot to the left of the tap, cold to the right. Keep the tails in smooth curves; never kinked, twisted or cross-threaded.

07 Flush and check

Open the supplies slowly and check every joint. Unscrew the aerator, run both supplies to flush debris, then refit it.

08 Swap the handle, if preferred

The knurled and smooth handles interchange without touching the plumbing — release the fitted handle as shown in the supplied handle instruction and seat the other. No tools on plated faces.

NOTE

This sequence is general to the Fonte Basin Mixer in both heights. Where the instruction supplied in the box differs, follow the supplied instruction. Guarantee: Termless.